## Shortening "Y" Tether Strap

"Instructions for shortening the upper restraint strap on Baby Capsule". Step 1. First loop the webbing as shown and push through one side of the A.R.F.A. #30GN Gated Buckle. Note: webbing must always be over the bar - not under. src="images/stories/pix-seatbelts/25 fitting gated buckle 1pt15.jpg" border="0" /> Step 2, Pull the double webbing through, allowing sufficient, as shown, to complete the procedure. <img src="images/stories/pix-seatbelts/28 fitting gated" buckle 1pt14.jpg" border="0" /> & Step 3. Pinch the 'double webbing" together as shown. <img src="images/stories/pix-seatbelts/27 fitting gated" buckle 1pt13.jpg" border="0" /> <br />Step 4. Now push the doubled web through the gate. <img src="images/stories/pix-seatbelts/32 fitting gated buckle" 1pt12.jpg" border="0" /> & Step 5. Both sides shown pushed equally, through the gate. <img src="images/stories/pix-seatbelts/36 fitting gated buckle 1pt11.jpg" border="0" /> Step 6. Push both sides down until flat against the centre, bar. <img src="images/stories/pix-seatbelts/31 fitting gated buckle 1pt10.jpg" border="0" /> & Step 7.<br />Take the excess and loop one side and then through the other. <img src="images/stories/pix-seatbelts/26 fitting gated buckle" 1pt9.jpg" border="0" /> & Step 8.<br />This phot shows the webbing flat behind the gate with both arms clearly visible.

src="images/stories/pix-seatbelts/33 fitting gated buckle 1pt8.jpg" border="0" /> Step 9.<br />Now pull the main webbing back to tighten... make sure the webbing stays flat and does not come out between the gate.

src="images/stories/pix-seatbelts/40-shorten-ytether-0281.jpg" border="0" /> % Step 10.<br/>br />The webbing is now ready for use. If fitted to the Capsule make sure the Buckle is as close to the Boss on either side as possible i.e. the front of the Capsule Base, not the Snap Hook end. <img src="images/stories/pix-seatbelts/29 fitting gated buckle 1pt6.jpg" border="0" /> %